

# elumen8

## **GB-1 Reflectabeam** User Manual



**Order code: ELUM076**

## WARNING

### FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY BEFORE YOUR INITIAL START-UP!

- Before your initial start-up, please make sure that there is no damage caused during transportation.
- Should there be any damage, consult your dealer and do not use the equipment.
- To maintain the equipment in good working condition and to ensure safe operation, it is necessary for the user to follow the safety instructions and warning notes written in this manual.
- Please note that damages caused by user modifications to this equipment are not subject to warranty.



#### IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorised modification to the equipment.

- Never let the power cable come into contact with other cables. Handle the power cable and all mains voltage connections with particular caution!
- Never remove warning or informative labels from the unit.
- Do not open the equipment and do not modify the unit.
- Do not connect this equipment to a dimmer pack.
- Do not switch the equipment on and off in short intervals, as this will reduce the system's life.
- Only use the equipment indoors.
- Do not expose to flammable sources, liquids or gases.
- Always disconnect the power from the mains when equipment is not in use or before cleaning! Only handle the power-cable by the plug. Never pull out the plug by pulling the power-cable.
- Make sure that the available mains supply voltage is between 100~240V AC, 50/60Hz.
- Make sure that the power cable is never crimped or damaged. Check the equipment and the power cable periodically.
- If the equipment is dropped or damaged, disconnect the mains power supply immediately and have a qualified engineer inspect the equipment before operating again.
- If the equipment has been exposed to drastic temperature fluctuation (e.g. after transportation), do not connect power or switch it on immediately. The arising condensation might damage the equipment. Leave the equipment switched off until it has reached room temperature.
- If your product fails to function correctly, stop use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Pro Light dealer for service.
- Only use fuses of same type and rating.
- Repairs, servicing and power connection must only be carried out by a qualified technician. THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.
- This fixture is for professional use only - it is not designed for or suitable for household use. The product must be installed by a qualified technician in accordance with local territory regulations. The safety of the installation is the responsibility of the installer. The fixture presents risks of severe injury or death due to fire hazards, electric shock and falls.
- Caution! This item is not designed to be used for extended periods of time. Risk assessment should be carried out based on the output power of the fixtures used for illumination, the distance from the GB-1 to fixtures and illumination time.
- WARRANTY: Two years from date of purchase.

#### OPERATING DETERMINATIONS

If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void. Incorrect operation may lead to danger e.g: short-circuit, burns and electric shocks etc.


Do not endanger your own safety and the safety of others!

Incorrect installation or use can cause serious damage to people and/or property.


### GB-1 Reflectabeam


Transform your beam effects with this innovative effect from eLumen8. Inside the robust, metal and fan cooled housing are 6 individually controllable multi-faceted dishes which can be rotated continuously in any direction at variable speeds. When strategically placed, the Reflectabeam can have beam effects aimed at them, producing a multitude of bright pin sharp shards of light that are reflected across walls and floors, adding an extra dimension to venues and dancefloors.

- 6 mirror dishes
- Individually controllable mirrors
- Auto, sound active and master/slave modes
- DMX channels: 2 or 8 selectable
- 4 push button menu with LED display
- PowerCON input/output
- 5-Pin XLR input/output
- Fan cooled housing



Specifications	GB-1 Reflectabeam
Power consumption	20W
Power supply	100~240V, 50/60Hz
Fuse	T2,5A 250V
Dimensions	250 x 250 x 120mm
Weight	3.72kg
Order code	ELUM076






- 01 - Earth point
- 02 - LED display
- 03 - Function buttons
- 04 - Microphone

- 05 - 5-Pin DMX input
- 06 - 5-Pin DMX output
- 08 - PowerCON output

- 09 - Fuse T2.5A 250V
- 10 - Cooling fan vents
- 11 - Omega clamp mounts

In the box: **1 x fixture,**  
**1 x power cable,**  
**1 x user manual,**  
**1 x omega clamp**  
**& 1 x safety eye**



## DMX mode:

Operating in a DMX control mode environment gives the user the greatest flexibility when it comes to customising or creating a show. In this mode you will be able to control each individual trait of the fixture and each fixture independently.

To access the DMX address mode, press the “**MENU**” button on the front of the unit to show *Addr* on the LED display. Now press the “**ENTER**” button and use the “**UP**” and “**DOWN**” buttons to set the required DMX address. Press the “**ENTER**” button to confirm the setting.

To exit out of any of the above options, press the “**MENU**” button.

To access the DMX channel mode, press the “**MENU**” button on the front of the unit to show *Chnd* on the LED display. Now press the “**ENTER**” button and use the “**UP**” and “**DOWN**” buttons to choose one of the 2 or 8 DMX channel modes. Press the “**ENTER**” button to confirm the setting.

To exit out of any of the above options, press the “**MENU**” button.

## 2 channel mode:

Channel	Value	Function
1	000-007	No function
	008-037	Macro 1
	038-067	Macro 2
	068-097	Macro 3
	098-127	Macro 4
	128-157	Macro 5
	158-187	Macro 6
	188-217	Macro 7
	218-247	Macro 8
	248-255	Sound active
2	000-255	Macro speed (when CH1 is 008-247), Sound sensitivity (when CH1 is 248-255)

## 8 channel mode:

Channel	Value	Function
1	000-005	Dish 1 no rotation
	006-126	Dish 1 rotation (fast-slow anticlockwise)
	127-128	Dish 1 no rotation
	129-249	Dish 1 rotation (slow-fast clockwise)
	250-255	Dish 1 no rotation
2	000-005	Dish 2 no rotation
	006-126	Dish 2 rotation (fast-slow anticlockwise)
	127-128	Dish 2 no rotation
	129-249	Dish 2 rotation (slow-fast clockwise)
	250-255	Dish 2 no rotation
3	000-005	Dish 3 no rotation
	006-126	Dish 3 rotation (fast-slow anticlockwise)
	127-128	Dish 3 no rotation
	129-249	Dish 3 rotation (slow-fast clockwise)
	250-255	Dish 3 no rotation
4	000-005	Dish 4 no rotation
	006-126	Dish 4 rotation (fast-slow anticlockwise)
	127-128	Dish 4 no rotation
	129-249	Dish 4 rotation (slow-fast clockwise)
	250-255	Dish 4 no rotation
5	000-005	Dish 5 no rotation
	006-126	Dish 5 rotation (fast-slow anticlockwise)
	127-128	Dish 5 no rotation
	129-249	Dish 5 rotation (slow-fast clockwise)
	250-255	Dish 5 no rotation
6	000-005	Dish 6 no rotation
	006-126	Dish 6 rotation (fast-slow anticlockwise)
	127-128	Dish 6 no rotation
	129-249	Dish 6 rotation (slow-fast clockwise)
	250-255	Dish 6 no rotation
7	000-007	No rotation
	008-037	Macro 1
	038-067	Macro 2
	068-097	Macro 3
	098-127	Macro 4
	128-157	Macro 5
	158-187	Macro 6
	188-217	Macro 7
	218-247	Macro 8
	248-255	Sound active
8	000-255	Macro speed (when CH7 is 008-247), Sound sensitivity (when CH1 is 248-255)

## Master/slave mode:

To set the master unit, press the “MENU” button on the front of the master unit to show *SLNd* on the LED display. Now press the “ENTER” button and use the “UP” and “DOWN” buttons to choose *MASt*. Press the “ENTER” button to confirm the setting. Then select your desired program (sound active, DMX or one of the built-in programs).

To set the other units in slave mode, press the “MENU” button on the front of the unit to show *SLNd* on the LED display. Now press the “ENTER” button and use the “UP” and “DOWN” buttons to choose either *SL 1* (Slave 1) or *SL 2* (Slave 2). Press the “ENTER” button to confirm the setting. The unit will now run in sequence with the master unit.

To exit out of any of the above options, press the “MENU” button.

Please ensure that all slave units are set to the same DMX channel mode as the master unit.

## Show mode:

To access the show mode, press the “MENU” button on the front of the unit to show *ShNd* on the LED display. Press the “ENTER” button to confirm the setting and the display will show *ShoU*.

To exit out of any of the above options, press the “MENU” button.

## Auto mode (built-in programs):

To access the auto modes, press the “MENU” button on the front of the unit to show *Auto* on the LED display. Now press the “ENTER” button and use the “UP” and “DOWN” buttons select which auto mode you require *Aut0* or *Aut8*. Press the “ENTER” button and use the “UP” and “DOWN” buttons to set the speed *1~9*. Press the “ENTER” button to confirm the setting.

**Value: 1 - 9 (1 = slow, 9 = fast)**

To exit out of any of the above options, press the “MENU” button.

## Sound active mode:

To access the sound active mode, press the “MENU” button on the front of the unit to show *SoUn* on the LED display. Now press the “ENTER” button and use the “UP” and “DOWN” buttons to set the sound mode *oN* or *oFF*. Press the “ENTER” button to confirm the setting.

To adjust the sound sensitivity, press the “MENU” button on the front of the unit to show *SenS* on the LED display. Now press the “ENTER” button and use the “UP” and “DOWN” buttons to set the sound sensitivity *0 ~ 100*. Press the “ENTER” button to confirm the setting.

**Value: 0 - 100 (0 = low sensitivity, 100 = high sensitivity)**

To exit out of any of the above options, press the “MENU” button.

### Setting the DMX address:

The DMX mode enables the use of a universal DMX controller. Each fixture requires a “start address” from 1- 511. A fixture requiring one or more channels for control begins to read the data on the channel indicated by the start address. For example, a fixture that occupies or uses 7 channels of DMX and was addressed to start on DMX channel 100, would read data from channels: 100,101,102,103,104,105 and 106. Choose a start address so that the channels used do not overlap. E.g. the next unit in the chain starts at 107.

### DMX 512:

DMX (Digital Multiplex) is a universal protocol used as a form of communication between intelligent fixtures and controllers. A DMX controller sends DMX data instructions from the controller to the fixture. DMX data is sent as serial data that travels from fixture to fixture via the DATA “IN” and DATA “OUT” XLR terminals located on all DMX fixtures (most controllers only have a data “out” terminal).

### DMX linking:

DMX is a language allowing all makes and models of different manufactures to be linked together and operate from a single controller, as long as all fixtures and the controller are DMX compliant. To ensure proper DMX data transmission, when using several DMX fixtures try to use the shortest cable path possible. The order in which fixtures are connected in a DMX line does not influence the DMX addressing. For example; a fixture assigned to a DMX address of 1 may be placed anywhere in a DMX line, at the beginning, at the end, or anywhere in the middle. When a fixture is assigned a DMX address of 1, the DMX controller knows to send DATA assigned to address 1 to that unit, no matter where it is located in the DMX chain.

### DATA cable (DMX cable) requirements (for DMX operation):

This fixture can be controlled via DMX-512 protocol. The DMX address is set on the back of the unit. Your unit and your DMX controller require a standard 3-pin XLR connector for data input/output, see image below.



Further DMX cables can be purchased from all good sound and lighting suppliers or Pro Light Concepts dealers.

Please quote:

**CABL10 – 2m**



**CABL11 – 5m**

**CABL12 – 10m**

**Note: DMX cable must be daisy chained and cannot be split.**

**Notice:**

Be sure to follow the diagrams below when making your own cables. Do not connect the cables shield conductor to the ground lug or allow the shield conductor to come in contact with the XLRs outer casing. Grounding the shield could cause a short circuit and erratic behaviour.



XLR Pin Configuration
Pin 1 = Ground
Pin 2 = Negative
Pin 3 = Positive

**Special note:**

**Line termination:**

When longer runs of cable are used, you may need to use a terminator on the last unit to avoid erratic behaviour.


**Using a cable terminator will decrease the possibilities of erratic behaviour.**

**(3-pin - Order ref: CABL90, 5-pin - Order ref: CABL89)**

Termination reduces signal transmission problems and interference. It is always advisable to connect a DMX terminal, (resistance 120 Ohm 1/4 W) between pin 2 (DMX-) and pin 3 (DMX+) of the last fixture.

**5-pin XLR DMX connectors:**

Some manufactures use 5-pin XLR connectors for data transmission in place of 3-pin. 5-pin XLR fixtures may be implemented in a 3-pin XLR DMX line. When inserting standard 5-pin XLR connectors in to a 3-pin line a cable adaptor must be used. The diagram below details the correct cable conversion.





***Correct Disposal of this Product  
(Waste Electrical & Electronic Equipment)***

**(Applicable in the European Union and other European countries  
with separate collection systems)**

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.



# elumen8

